



Loosen the screws.



Put the barrel through mount.



Put the batteries into the barrel,
screw on the rail-tail switch.



Attach to the gun tube.



Screw on the mount tightly with
tool.



Remove original tailcap.



Remove the cover of magic sticker.



Replace the rat tail switch assembly.



Fix to the gripe of gun.



Fix to the gun tube with mount.